

# Screw Connector PG20



The most basic way to attach 2 extrusions at right angles is to simply bolt them together like you would a 2×4. These screw connectors require that you tap the center hole in one extrusion with an M6 tap and access for an allen key drilled in the opposite extrusion so the bolt can be tightened.

## **Product Specifications**

### **Look-up Reference**

Catalogue Page 93

Manufacturer Part Number 3.81.06

### **Physical Properties**

T-Slot Profile Size PG20