


Ball Screw Support Bearing for SFU16 Ball Screws



Both ends of a ball screw need to be supported by a bearing. This bearing is used on the free end of the screw. The snap ring that is included is used to secure the bearing in place on the screw. This bearing is for 16mm ball screws.

Ball Screw Assembly

Here is an example of a ball screw assembly.



Product Specifications

Physical Properties

Bearing Type Ball Screw (Support)

Look-Up Reference

Catalogue Page 55

Manufacturer Part Number BF12

Ball Screw Series SFU16