

RTD Phidget



For applications that require precise temperature measurement, you'll find that an RTD is often prescribed by the experts. The resistance of the element inside an RTD will change with temperature, and because it's made of a pure metal (usually platinum), this resistance value will change in a precise and repeatable way. The RTD Phidget measures these subtle changes, so you can get the most accurate temperature measurements sent right to your **VINT hub**. See the "Compatible Products" tab for a list of VINT Hubs.

Easy-to-use API

Setup is easy with this adapter; you can choose the number of wires that your RTD has (2, 3, or 4), and then select the type of RTD you're using (PT100, PT1000, etc.) with commands in our API. The adapter does all the math, leaving you with the sampled temperature in degrees Celsius.

Thermistor Compatible

You can also read thermistors and other resistive sensors by using the resistance sensor object in your program. You'll receive the data in ohms, and can convert to the desired unit by using the formula in your sensor's datasheet. You could even use it as a simple ohmmeter for resistances up to 19 k Ω .

Product Specifications

Board Properties

Controlled By VINT

Resistance Input

Maximum Measurable Resistance 50 k

RTD Input

Temperature Error Max 0.2 °C

RTD Current Max	62 $\frac{1}{4}$ A
Sampling Interval Min	250 ms/sample
Sampling Interval Max	60 s/sample

Electrical Properties

Current Consumption Min	17 $\frac{1}{4}$ A
Current Consumption Max	4 mA

Physical Properties

Recommended Wire Size	16 – 26 AWG
Operating Temperature Min	-40 °C
Operating Temperature Max	85 °C